

BLOCK PROTECTION using DZ-1008 and DZ-1050 or DZ-1050V (variable delay)

This circuit is repeated for each block.
Blocks should be at least one train length.

note: This only works for a single direction
of train travel.

