

## DZ-1010 problems

Start by testing only the DZ-1010 separate from the DZ-1012 slave. Apply power and see if the signal will time out and the if the arm will then go up. If not, remove the bottom and rotate the motor with your thumb. Once the gate arm is up, try powering it. Touching the BLU wire to the BLK wire should activate it.

The 1012 slave can be tested separately as well, but the SW#2 must be moved to OFF. Then, it should test like the 1010.

If they are each working then put SW#2 back in the ON position, connect both units to power and connect the BLU wires together. If the units are aligned correctly the gate arms will go up. Blocking the beam will cause the arms to lower, time out and go back up.

If all this fails, you can call the number below, if necessary, we'll have to return the unit for repair.