

## DZ-1008 Relay Testing

Connect RED to 12-14VAC power

Connect BLK to COMMON

First test:

Touch GRN to RED and relay should click.

- If it does, relay is good so far
- If not, relay is bad

Connect BLU to RED

Connect one lead of TESTER to BLK

Touch other lead of TESTER to GRAY, tester should light or show a connection, but touching WHT should not light or show connection.

Connect GRN to 12-14VAC – RED wire

Touch other lead of TESTER to WHT, tester should light or show connection, but now touching GRAY should not light or show connection.

If that is all true, the RELAY is good.